

SWIX SMØRETIPS

Toblach/Dobbiaco-Cortina

For søndag (renndag) 05.02.2023

På grunn av forventet endring i vær og føre er smøretipset utarbeidet på grunnlag av vår tidligere erfaring fra løypa og værvarsel fra yr.no.

VÆR- og TEMPERATURER for søndag (basert på opplysninger fra yr.no)

Det er meldt kaldt i natt.

Lago di Landro (start)	09:00	-10,0°C
Lago di Dobbiaco	10:00	-9,0°C
Lago di Landro	11:00	-7,0°C
Fiames	12:00	-5,0°C

STRUKTUR

Swix Rillejern: 2,0 mm rett rill (pregevelse som ruller og gir rett struktur). lett trykk på bakskien

GLID – Enkelt alternativ (Fluorfritt)

1. Smelt inn **HS06**. Avkjøles. Varmes inn én gang til, avkjøles, skrapes av med en plexisikling og børstes med Swix bronse- eller stålborste.
2. Avslutt med Swix rød eller blå nylon poleringsbørste.

GLID – Racing alternativ (Fluorfritt)

1. Smelt inn **DHFF Hvit Marathon** Avkjøles. Varmes inn én gang til. Skrapes av med en plexisikling og børstes med Swix bronse- eller stålborste.
2. Smelt inn **TSP06** blått fluorfritt pulver, varmes inn på 160 grader. Avkjøles. Skrapes av med en plexisikling og børstes godt med Swix bronse- eller stålborste.
3. Avslutt med Swix rød eller blå nylon poleringsbørste.

Swix ønsker alle en riktig god tur!

SWIX WAX TIPS

Toblach/Dobbiaco-Cortina

For Sunday (raceday) 05/02/2023

Because of expected change in weather and conditions, our wax recommendations are based on earlier experiences from the track and the forecast from yr.no.

WEATHER and TEMPERATURES for Sunday (based on info from www.yr.no)

The forecast says colder over the night.

Lago di Landro (start)	09:00	-10,0°C
Lago di Dobbiaco	10:00	-9,0°C
Lago di Landro	11:00	-7,0°C
Fiames	12:00	-5,0°C

STRUCTURE

Swix Structure Tool: 1.0 mm linear structure (imprint roller that gives linear structure). Use a medium pressure. Behind the kicksone

GLIDE: Alternative 1 – easy (non fluor)

1. Iron in **HS06**. Let cool off. Iron in once more and let cool off. Scrape off with a Swix Plexi Scraper, and brush with a Swix Bronze or Steel Brush.
2. Finish with the Swix red or blue nylon polish brush.

GLIDE: Alternative 2 – more experienced

1. Iron in one layer of **DHFF White Marathon**. Let cool off. Iron in once more and let cool off. Scrape off with a Swix Plexi Scraper, and brush with a Swix Bronze or Steel Brush.
2. Iron in one layer of **TSP06** fluorfree blue powder, Let cool off. Scrape off with a Swix Plexi Scraper, and brush with a Swix Bronze or Steel Brush.
3. Finish with the red or blue nylon polish brush.

We wish everybody a nice trip!